## BANDIT® SERIES PROFESSIONAL BELT DRIVE PRESSURE WASHERS

## FEATURES

- » Honda engines with low oil protection
- » Premium Series industrial Comet triplex pump
- » External unloader and bypass system
- » Ultra lightweight aluminum frame with 1 1/4" tubing operator handle
- » 13" rugged FLAT FREE tires
- » Easy access two piece aluminum belt guard
- » 3-groove "Bandit" belt for uniform tension and maximum power transfer
- » "EZ-line" belt tension assembly
- » Thermal relief safety protection
- » User friendly engine oil drain system
- » 50 mesh stainless steel inlet filter
- » 3/4" cold rolled steel axle
- » Dual anti-vibration rubber isolators

Units include 50' steel braided non-marking gray hose, 36" spray wand with molded grip and gun, 5 quick connect spray nozzles, and a high draw chemical injector. Hose reel kits and other options are available. See your PSI dealer for details.









HONDA

POWERED by







## PUMP FEATURES:

- » Forged brass manifold with lifetime warranty
- » Forged one piece bronze alloy connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » Premium quality oversized tapered roller bearings
- » Increased fin depth for maximum heat dissipation
- » Large crankcase capacity for improved cooling
- » Special PSI offering: 1 year "Bumper-to-Bumper" warranty on entire pump – includes all normal wear items



"The Original" B-4040HC

## SPECIFICATIONS

MODEL	PSI	GPM	TIRES	ENGINE	PUMP	DIMENSIONS	UNIT WEIGHT
B-4040HC	4000	4.0	13"	Honda GX390	RW4040S	43" x 26" x 27"	144 lbs.
B-5530HC	3000	5.5	13"	Honda GX390	RW5535S	43" x 26" x 27"	144 lbs.



**Pressure Systems Innovations** 

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404

Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com www.PressureSystemsInnovations.com