

DRAGON SERIES HOT WATER PRESSURE WASHERS

FEATURES

- » Electric start gasoline GX390 Honda engine or commercial grade electric motor
- » Industrial Comet triplex pump with external unloader and bypass
- » Rugged roll cage design with lifting hook – protects all unit components
- » Stainless steel control panel with adjustable temperature control
- » 6 gallon poly diesel/kerosene fuel tank
- » Easy engine oil drain system

**POWERED by
HONDA™**

**STAINLESS
STEEL**
OPTION AVAILABLE



D-H4040HC

Units include 50' steel braided non-marking gray hose, 36" insulated spray wand with molded grip and gun, 5 quick connect spray nozzles, and a high draw chemical injector. Other kit options are available. See your PSI dealer for details.

PSI pressure washers feature Comet pumps for their unmatched quality and life.

**5 YEAR
LIMITED
COMET
PUMP
WARRANTY**



PUMP FEATURES:

- » Forged brass manifold with lifetime warranty
- » Forged bronze connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » High quality oversized bearings
- » Increased fin depth for maximum heat dissipation

**3 YEAR
LIMITED
HONDA
ENGINE
WARRANTY**

SPECIFICATIONS

MODEL	PSI	GPM	TIRES	ENG/MOTOR	PUMP	DIMENSIONS	UNIT WEIGHT
D-H4040HC	4000	4.0	13"	Honda GX390	ZWD4040	45" x 32" x 47"	500 lbs.
D-H5030HC	3000	4.0	13"	Honda GX390	ZWD5030	45" x 32" x 47"	500 lbs.
D-H2015BC	1500	2.1	10"	Baldor 2 hp	LWS2020E	42" x 27" x 42"	400 lbs.



Pressure Systems Innovations

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404

Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com

www.PressureSystemsInnovations.com