PHANTOM E SERIES

PROFESSIONAL DIRECT DRIVE ELECTRIC PRESSURE WASHERS

FEATURES

- » Commercial grade electric motors
- » Industrial Comet triplex pump with external unloader and bypass
- » Ultra lightweight corrosion resistant frame with 1 1/4" tubing operator handle
- » Adjustable pressure
- » 10" tubed pneumatic tires
- » Thermal relief protection
- » 50 mesh stainless steel inlet filter
- » 3/4" cold rolled steel axle
- » Dual anti-vibration rubber isolators

Units include 50' steel braided non-marking gray hose, 36" spray wand with molded grip and gun, 5 quick connect spray nozzles, and a high draw chemical injector. Hose reel kits and other options are available. See your PSI dealer for details.



PSI pressure washers feature Comet pumps for their unmatched quality and life.





PUMP FEATURES:

- » Forged brass manifold with lifetime warranty
- » Forged bronze connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » High quality oversized bearings
- » Increased fin depth for maximum heat dissipation



SPECIFICATIONS

MODEL	PSI	GPM	RPM	VOLTS	AMPS	PUMP	HP
P-E2015BCX*	1500	2.0	3450	120	18.5	BXD2020E	2.0
P-E2015BCL*	1500	2.0	1750	120	18.0	LWS2020E	2.0
P-E2015BCH*	1500	2.0	3450	120	19.0	LWD2020E	2.0
P-E3522BCH**	2500	3.5	3450	240	19.0	LWD3522E	5.0

* Units come standard with switch, box, cord, GFCI and 20A plug. Meets UL standards.

** P-E3522BCH with switch, box and cord. GFCI is optional.



Pressure Systems Innovations

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404

Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com

www.PressureSystemsInnovations.com